



FIG. 1





FIG. 2






FIG. 3

FIG. 4

### CALLED PARTY NUMBER DECODE

	LENGTH	OCTET	ID
NATURE CONNECTION	1	16	
FORWARD CALL INDICATORS	2	17 & 18	
CALLING PARTY'S CAT	1	19	
POINTER TO USER SERVICE INFORMATION	1	20	A
LENGTH OF USER SERVICE INFORMATION	1	20 + A OR A	C
USER SERVICE INFO	C	20 + A + I TO 20 + A + I + C	
POINTER TO CALLED PARTY NUMBER	1	21	D
LENGTH INDICATOR FOR CALLED PARTY NUMBER	1	21 + D OR D	E
CALLED PARTY NUM	D	21 + D + I TO 21 + D + I + E	
POINTER TO START OF OPTIONAL PART	1	22	

FIG. 5

## HEX CONVERSION

BIN	H	D
0000	0	0
0001	1	1
0010	2	2
0011	3	3
0100	4	4
0101	5	5
0110	6	6
0111	7	7
1000	8	8
1001	9	9
1010	A	10
1011	B	11
1100	C	12
1101	D	13
1110	E	14
1111	F	15

**BIN POSITION VALUE**

### HEX POSITION VALUE

FIG. 6




FIG. 7

